

Film Threading

1. Pull the carrier forward to raise the upper glass.
2. Place the roll of film on the spindle (left side) so that the film unwinds from the right side of the film roll.
3. Thread the film under the first roller, over the second roller, across the lower glass, over the third roll, under the fourth roller, and insert the film into the slot on the take-up roller.

